


North York Regional Fire Department Kenwood TK-2180 Portable User Guide

Key Assignments



<u>Key</u>	<u>Normal Function</u>	<u>2nd Function</u>
S	Scan	-
A	Scan Add/Delete	-
<B	-	-
C>	Zone Up	-

Top (Orange)	Function Shift*	Clock
Side 1 (Upper)	-	Monitor
Side 2 (Lower)	Lamp	Talk Around

*Press this key to access the 2nd function assigned to a key.

ZONE 1 - FIRE	
CH	NAME
1	CRABBE SIMPLEX
2	CRABBE REPEATER
3	MUTUAL AID
4	TAC 1
5	TAC 2
6	KESWICK RIDGE SIMPLEX
7	KESWICK RIDGE REPEATER
8	NEW MARYLAND FD
9	UPPER KINGSCLEAR FD
10	NASHWAAK VALLEY FD
11	STANLEY FD
12	CRABBE SKI REPEATER
13	DNR FIRE 1
14	DNR FIRE 2
15	KESWICK PAGE
16	MILLVILLE PAGE

ZONE 2 - DNR	
CH	NAME
1	FIRE REPEATER 1
2	FIRE REPEATER 2
3	FIRE SIMPLEX 1
4	FIRE SIMPLEX 2
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	

ZONE 3 - GSAR	
CH	NAME
1	YSSR
2	RVSAR
3	TRISAR
4	NAT SAR
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	

ZONE 4	
CH	NAME
1	AMBULANCE
2	RCMP
3	NB POWER
4	WEATHER
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	